

1. Go to [eg4electronics.com/downloads](http://eg4electronics.com/downloads)
2. Download the firmware here

For any firmware marked with an asterisk (\*), it is not a required update, but should only be installed at the direction of a technical support agent from your distributor.

## Inverters




For any firmware marked with an asterisk (\*), it is not a required update, but should only be installed at the direction of a technical support agent from your distributor.


## Ground Mounts and Air Conditioners

3. Open the downloaded File


For any firmware marked with an asterisk (\*), it is not a required update, but should only be installed at the direction of a technical support agent from your distributor.




4. extract the file




#### 4. Open the New V2 3k folder




#### 5. Open the IAPTool application




6. Click more info



## 7. Click Run Anyway




8. Find the correct COM port



9. Browse for the file name



## 10. Select the V2 File



## 11. Start the update

