

## **Guide for changing Baud-Rate the on the EG4 Lifepower4 Communication Hub**

**Lifepower4 firmware V3.26 has baud rate changed from 9600 to 19200 on pins 7,8. This guide will show you have to change the baud rate on the communication hub.**

- 1. Hold down the Enter button until the parameter settings menu has appeared.**
- 2. Now click down until reaching the parameter settings 3/3**
- 3. BMSUART Baudrate will appear on this tab, 9600-0 is set by default. To change this click enter and now the 9600-0 will be highlighted, now click up to change to 19200-1. Now click enter.**
- 4. You can now click back to leave the parameter settings menu. You have now successfully changed the baud-rate of the communication hub.**

**A guide with photos is included below.**



1. Hold down the Enter button until the parameter settings menu has appeared.



2. Now click down until reaching the parameter settings 3/3





3. BMSUART Baudrate will appear on this tab, 9600-0 is set by default. To change this click enter and now the 9600-0 will be highlighted, now click up to change to 19200-1. Now click enter.



4. You can now click back to leave the parameter settings menu. You have now successfully changed the baud-rate of the communication hub.