

EG4 ELECTRONICS

Cables Needed For Updating EG4 Electronics Batteries

Lifepower4 BMS Update- RS485 RJ45 Pins (1-B, 2-A)
Lifepower4 V2 BMS Update- RS232 RJ45 Pins (4-Rx, 5-Tx) Lifepower4 V2 LCD Update- RS485 RJ45 Pins (1-B, 2-A)
AllWeather Wallmount BMS Update- RS232 RJ45 Pins (4-Rx, 5-Tx) AllWeather Wallmount LCD Update- RS485 RJ45 Pins (1-B, 2-A)
51.2V 280Ah Indoor BMS Update- RS232 RJ45 Pins (4-Rx, 5-Tx) 51.2V 280Ah Indoor LCD Update- RS485 RJ45 Pins (1-B, 2-A)
EG4 LL V2/LL-S BMS Update- RS232 RJ45 Pins (4-Rx, 5-Tx) EG4 LL V2/LL-S LCD Update- RS485 RJ45 Pins (1-B, 2-A)
EG4 LL V1 LCD Update- RS485 RJ45 Pins (1-B, 2-A)
EG4 LL V1.1 12V 400AH BMS update- RS232 RJ45 Pins (4-Rx, 5-Tx)