

EG4® LL 48V BATTERIES

SOC RECALIBRATION GUIDE (ACTUAL REMAINING CAPACITY)



**Image above shows an EG4 LL-S 48V 100Ah battery*

PURPOSE

For use after a Battery Management System's (BMS) Printed Circuit Board (PCB) replacement has been completed. The new BMS PCB will not accurately know the LiFePO4 cell pack it is managing. Due to this new learning curve, the BMS will need to learn the cell pack's State of Health % (SOH = Total Remaining Capacity) and the State of Charge % (SOC = Actual Remaining Capacity). SOC% drift is a natural occurrence that can occur over time if the battery is never Top Balanced or Bottom Balanced.

Top Balancing

The EG4-LL line of batteries will automatically recalibrate the SOC to 100% whenever one cell has reached the Cell Overvoltage Alarm at 3.7V while charging. To ensure this happens, use a DC charger that is **SAFE** to use with Lithium-Ion batteries, or specifically a LiFePO4 (Lithium Ferrous Phosphate) battery charger. Apply a 57.0VDC charging voltage at 50A. This will ensure a safe power threshold for the battery to reach the Cell Overvoltage Alarm at 3.7V. Once this alarm occurs, the SOC will round to 100%.

Bottom Balancing

The EG4-LL line of batteries will automatically recalibrate the SOC to 0% whenever one cell has reached the Cell Undervoltage alarm at 2.5VDC.

To ensure this happens, use a 48VDC load bank or inverter. Apply a 50A discharge current to the individual battery. This will ensure a safe power threshold for the battery to reach the Cell Undervoltage alarm at 2.5VDC. Once this alarm occurs, the SOC will round down to 0%.

BATTERY COMPATIBILITY

EG4® LL-S 48V, LL-V2 48V, LL-V1 48V, & LifePower4 V2 48V batteries



NOTE:

A monthly maintenance routine should be performed to ensure the SOC recalibration remains accurate. It is recommended to perform the recalibration once a month to ensure the battery bank remains calibrated.