



### **PowerPro 280ah 51.2V changelog for heater Logic**

- Currently on this firmware (**S02T09**) the new heater logic is whenever all (4) temperature sensors 1-4 reach below 0C the heater will turn on and draw a 4 amp discharge until all (4) temperature sensors 1-4 reach 6C the heater will power off. The heater will not function at 10% SOC or below.